



## Testing Water For Pesticides Rivers, Streams, Lakes, Ponds Reservoirs and Wells

**There's an old scientific axiom that says the result of any test can be no better than the sample on which it is performed. Proper procedures must be followed to ensure the analysis is accurate.**

**Samples for pesticide analyses must be handled in such a way that they do not deteriorate or become contaminated before they reach our laboratory**

### WELL WATER

1. Collect a sample only after the well has been pumped sufficiently to ensure that the sample represents the groundwater source. Three to five minutes should be adequate. Make sure that the sample is drawn before it passes through any treatment device such as a water softener or filter
2. Collect at least one quart in a clean, amber-glass bottle. Rinse the bottle 2 or 3 times with the water to be sampled before making the collection. Cap the bottle with a Teflon lined plastic lid. Seal the cap with gummed tape. Code each bottle and record the date, time and the number of the sampler. Shipping kits are available from A&L Canada.
3. Some Pesticides break down quickly in water. The sample must be kept refrigerated at 34 to 38 °F until all tests are completed.
4. Ship the sample as soon as possible to ensure that it is received at our laboratory within 48 hours after collection, as all water analyses must be completed with 14 days of collection.

### LAKES, PONDS AND RESERVOIRS

**Lake and pond waters are subject to considerable variations due to rain, runoff, wind and seasonal stratification.**

1. The location, depth and frequency of sampling will depend on local conditions. Analytical composition is likely to vary with both the depth and the horizontal location. Under most conditions, neither total nor average figures are especially significant. Local variations are more important to the sampler. Therefore; collect samples separately. Do not composite them.
2. The care and storage of the samples remain the same as that for well water.

### RIVERS AND STREAMS

**The analytical composition of the water may vary with depth, stream flow and the distance the sample is taken from the shore.**

**Knowledge of the volume, movement and composition of the various parts of the water being sampled is required.**

1. A grab or catch sample can be taken if the source is constant in its composition over a considerable period of time or over substantial distances in all directions. Take the sample in the middle of the stream at mid-depth.
2. An "integrated" sample should be taken if the analytical composition of the water varies with the width and depth of the source. However, integrated sampling is a complicated process and usually requires special equipment.
3. The care and storage of the samples remain the same as that for well water

FACT SHEET

A & L CANADA  
LABORATORIES, INC.

2136 Jetstream Rd.  
London, ON N5V 3P5

Phone: 519-457-2575  
Fax: 519-457-2664  
Aginfo@alcanada.com  
www.alcanada.com

Fact Sheet No. 952  
Revised 11/2013

## SHIPPING INSTRUCTIONS.

1. Place the refrigerated sample in a Styrofoam or other insulated container. Pack the sample in ice or use prefrozen packs. Secure the sample in the container to prevent breakage.
2. Complete the instructions form and enclose it with the sample. The legal integrity of the sample can be maintained by including a Chain-of-Custody form that indicates the sampler's name and the date and time the sample was taken.
3. Ship the sample via UPS Overnight, Federal Express or other similar service. It is important that the sample be received at our lab within 48 hours after it was collected. Ship on Monday, Tuesday or Wednesday to avoid a weekend delay.